



## Sprinter / Crafter Bonnet Bra Fitting Instructions

**Before You Begin Fitting Your Product, Please Ensure Your Bonnet Is Clean  
And Dry.**

**We recommend you visit our website for photos and more instructions:  
<http://www.van-x.co.uk/instructions>**

**\*\*\* PLEASE ENSURE YOU HAVE THE CORRECT BONNET BRA FOR YOUR  
VEHICLE \*\*\***

1. Please try to fit on a warm day if you can, because the heat will make the bonnet bra more flexible.
2. Open the bonnet and fit the top corners then the bottom corners.



3. Tie the bonnet bra using the rope provided, threading the rope through opposite loops, try not to pull too hard.



4. After initial fitting pour hot water over the cover (this helps the cover to fit to your vehicle).



5. Check the tension in the ropes and tighten, if necessary.
6. Apply some tyre shine or wax to the bra, to improve the finished appearance.



7. Now your bonnet cover is ready! Enjoy!

**If You Still Have Problems/Difficulties Fitting Your Bonnet Bra, Please Contact Us:**

**Telephone:** 01782 280 888 | **E-Mail:** [info@van-x.co.uk](mailto:info@van-x.co.uk) | **Website:** [www.van-x.co.uk](http://www.van-x.co.uk)  
| **WhatsApp:** 01782 454 897