



VAN-X CAB DIVIDER CURTAIN FITTING INSTRUCTIONS

Before You Begin Fitting Your Product, Please Ensure You Have Received the correct Curtain Kit(s) By Checking Your Order Invoice(s) With The Packaging Labels. Please Read These Instructions Very Carefully Before Fitting.

What is included in your Van-X Curtain Kit:

- 2 x Van-X Curtains (with 2 poppers to the outer side of each curtain)
- 1 x Van-X Flat Curtain Rail
- 2 x End Caps
- 2 x Van-X Curtain Tie-Backs
- 4 x Male Poppers
- Screws (for attaching Van-X Rail & Male Poppers)
- 1 x Bending Tool

You will need the following tools:

- Drill
- Riveter
- Tape Measure
- Hacksaw

1. Carefully unpack the curtains - Please do not use a knife or a sharp blade.
2. Measure the width of your vehicle roof and cut the flat rail accordingly. The rails are slightly flexible and can be bent to fit the contour of the roof lining if required but please allow for this in your measurements.

Please Note: The roof lining width can vary so please make sure you measure before cutting the flat rail.

3. Apply one end cap to one side of the rail. Decide where you would like your rivets to go and drill the holes to the rail with the roof lining only. These holes need to be made in the widest channel of the rail. Now fix your rivets into the rails and the roof lining. We recommend that you use 6-7 rivets.

Please Note: When attaching the rails to the roof lining please make sure the edge with the widest channel is facing toward the rear seats.

4. You are now ready to attach your curtains. We recommend that you slide 4-5 hooks along your top rail making sure that 2 large poppers are on the outer side of the material.
5. Continue the process until all the hooks are fitted and then fit the second curtain through the rails exactly the same method but make sure the second curtain has the 2 large poppers facing the opposite side wall of the van interior.
6. At this point, make sure that you have fitted all of the end caps to the rails.
7. Now that the curtains are fitted, look at the end of the curtain with the large poppers facing the outer edge as these need to be attached to the side wall of the van interior to help improve their appearance and fit. To fit the 4 large male poppers, please fix where necessary with a rivet or 4 screws included in this kit. **(Please view the image below for an example how the large male poppers on the side wall align up with the female poppers off the curtains.)**



8. There are 2 tie-backs supplied within the kit, these are used to attach around the cab divider curtains when they are open. You can use these tie-backs as an option for your cab divider as the curtains will stay in place on their own.

When closing the cab divider curtains in your van, attach the two curtain pieces with the three poppers already fitted to the material.



9. Your new Van-X Cab Divider Curtains are now ready!



If You Still Have Problems/Difficulties Fitting Your Curtains, Please Contact Us:

Telephone: 01782 280 888 | **E-Mail:** info@van-x.co.uk or info.vanx@gmail.com

Website: www.van-x.co.uk